




DE	RF	DRAWN BY	DART AEROSPACE USA, INC.
CI	CHECKED APPROVED		DRAWING NO. REV.
	A	#	D2922 SHEET 1 OF
D/	ATE		TITLE SCAL
9	99.10.14		OH-58 SKIDTUBE ASSEMBLY NT
1	A	99.10.14	NEW ISSUE
1	AI of CP	01.08.20	\$0.640 WAS \$0.625



Qty	Part Number	Description
X	D2922-041	SKIDTUBE ASSEMBLY
*	D2600-1	EXTRUSION
1	D2646	AFT CAP
4	D2648-3	WEARPAD
. 1	D2648-5	WEARPAD
22	D2649	CROSS BOLT SPACER
20	D2651-1	PLUG
20	D2651-3	O-RING
1	D2656-15	WEARSHOE
1	D2656-21	WEARSHOE
1	D2794	CAP
1	D2923	WEB
1	D2924	WEARSHOE
50	AKS7-1032-130	INSERT
	or AKS4-1032-130	
	or ALS7-1032-130	
	or ALS4-1032-130	
52	AN960JD10L	WASHER
52	MS27039-1-08	SCREW

GENERAL NOTES:

- 1) TOLERANCES ARE PER DART QSI 018 UNLESS OTHERWISE NOTED
- 2) LENGTH OF D2600-1 EXTRUSION REQUIRED BEFORE BENDING = 160 INCHES.*
- 3) INSERT D2923 WEB TO LOCATION SHOWN OFF AFT END OF SKIDTUBE AND BOND WEB INTO OUTER TUBE WITH NON-STRUCTURAL SIKAFLEX-241/291 ADHESIVE PER DART QSI 015 AFTER BENDING.
- 4) USE DART DRILL TEMPLATE DT8406 TO LOCATE AND DRILL Ø0.297 HOLES FOR WEARSHOE INSERTS. INSTALL AKS7-1032-130 PER SECTION D-D (50 PLACES) AFTER FINISH. INSTALL MS27039-1-08 SCREWS AND AN960JD10L WASHERS IN ALL INSERTS. SEAL WITH SIKAFLEX-241/291.
- 5) WELDING TO BE DONE PER DART QSI 004.
- 6) FINISH:
 - ACID ETCH, ALODINE PER DART QSI 005 4.1 PRIOR TO INSERTING D2923 WEB POWDER COAT ASSEMBLY GLOSS WHITE (REF 4.3.5.1) PER DART QSI 005 4.3 BLACK ANTI-SKID PAINT AS INDICATED TO 0.50 ABOVE LOCATION RIDGE PER DART QSI 005 4.4
- INSERT D2651-1 PLUG C/W D2651-3 O-RING IN HOLES MARKED 'P' (BOTH SIDES OF TUBE) AFTER FINISH (20 PLACES).



Copyright 1999 by DART AEROSPACE USA, INC.